



# Acoustical Surfaces, Inc.

**SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION CONTROL SPECIALISTS**

123 Columbia Court North • Suite 201 • Chaska, MN 55318

(952) 448-5300 • Fax (952) 448-2613 • (800) 448-0121

Email: [sales@acousticalsurfaces.com](mailto:sales@acousticalsurfaces.com)

Visit our Website: [www.acousticalsurfaces.com](http://www.acousticalsurfaces.com)

---

---

***We Identify and S.T.O.P. Your Noise Problem***



**MICROSTAT LABORATORIES**

**RIVER'S EDGE TECHNICAL SERVICE**

Specialists in Materials Testing and Technical Services

---

## TEST REPORT

Rendered by Manufacturer and Released to:

Acoustical Surfaces, Inc.

123 Columbia Court North

Chaska, MN 55318

Organic analysis of expanded polypropylene (ARPRO EPP with anti-stat) molded samples using a Fourier Transformed Infrared Spectrometer for Silicone (Dimethicone) and Liquid Particle Counting (LPC).

Report #: 2006-129

October 25, 2006

---

211 North Main, PO Box 115, Dover, MN 55929 USA • Phone: 507-932-3968 • Toll Free: 877-204-2007 • Fax: 507-932-3979 • [www.microstatlabs.com](http://www.microstatlabs.com)

---

• Soundproofing Products • Sonex™ Ceiling & Wall Panels • Sound Control Curtains • Equipment Enclosures • Acoustical Baffles & Banners • Solid Wood & Veneer Acoustical Ceiling & Wall Systems  
• Professional Audio Acoustics • Vibration & Damping Control • Fire Retardant Acoustics • Hearing Protection • Moisture & Impact Resistant Products • Floor Impact Noise Reduction  
• Sound Absorbers • Noise Barriers • Fabric Wrapped Wall Panels • Acoustical Foam (Egg Crate) • Acoustical Sealants & Adhesives • Outdoor Noise Control • Assistive Listening Devices  
• OSHA, FDA, ADA Compliance • On-Site Acoustical Analysis • Acoustical Design & Consulting • Large Inventory • Fast Shipment • No Project too Large or Small • Major Credit Cards Accepted



# Acoustical Surfaces, Inc.

**SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION CONTROL SPECIALISTS**

123 Columbia Court North • Suite 201 • Chaska, MN 55318

(952) 448-5300 • Fax (952) 448-2613 • (800) 448-0121

Email: [sales@acousticalsurfaces.com](mailto:sales@acousticalsurfaces.com)

Visit our Website: [www.acousticalsurfaces.com](http://www.acousticalsurfaces.com)

---



---

**We Identify and S.T.O.P. Your Noise Problem**

## SUMMARY

### *FTIR Analysis*

The sample tray was received and processed for FTIR analysis of expanded polypropylene (ARPRO EPP with anti-stat) for Silicone and liquid particle analysis by liquid particle counter (LPC).

A sample tray of material was extracted in enough hexane to cover for 10 minutes. Then the hexane was evaporated. The resulting extract was allowed to evaporate to a dry residue. The residue was extracted with 5-ml hexane and evaporated onto a Horizontal Attenuate Total Reflectance (HATR) trough plate drop wise. The remaining residue was extracted with 2-ml of hexane and evaporated onto the HATR with the residue from previous extract. The HATR was placed in a FTIR and the residue was analyzed. The FTIR spectrum was compared to that of silicone oil. The four signature peaks for silicone oil are at approximately 1258, 1088, 1017 and 796  $\text{cm}^{-1}$ .

### *Liquid Particle Counting (LPC) Analysis-Zero-Stress Method*

A sample was placed in a clean tray with 1000-ml ultrapure deionized water, from which a method blank had been taken. Then 500-ml of ultrapure deionized water was poured over entire surface. The sample was allowed to remain for 1 minute, while being slosed ten times, then the sample was removed and then flipped over and slosed ten more times in one minute. The sample was removed and three 20-ml aliquots were taken using a PMS CLS-200 liquid particle counter. The results are reported in counts/ $\text{cm}^2$  and counts/ $\text{in}^2$ . A single count represents a single particle at the various size distributions.

## DISCUSSION

Silicone (dimethicone) was not present in the two samples and the major peaks identified represent polypropylene residue from extraction. There was very little residue from the sample and a large scaling had to be used to obtain most of the peaks. The results of the LPC analysis are listed in the table below.

**Table 1. Particle Generation Results of ARPRO EPP Sample.**

Trial 1	Counts/ml	Method Blank Counts/ml	Counts/ $\text{cm}^2$	Counts/ $\text{in}^2$
$\geq 0.3 \mu\text{m}$	943.1	59.1	4087.5	26371.4
$\geq 0.5 \mu\text{m}$	498.3	14.6	2236.6	14429.7
$\geq 1.0 \mu\text{m}$	222.1	6.0	999.2	6446.7
$\geq 2.0 \mu\text{m}$	79.1	3.2	351.0	2264.2
$\geq 3.0 \mu\text{m}$	43.8	2.4	191.4	1235.0
$\geq 5.0 \mu\text{m}$	18.1	1.2	78.1	504.2
$\geq 10.0 \mu\text{m}$	5.2	0.3	22.7	146.2
$\geq 15.0 \mu\text{m}$	2.5	0.1	11.1	71.6



# Acoustical Surfaces, Inc.

SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION CONTROL SPECIALISTS

123 Columbia Court North • Suite 201 • Chaska, MN 55318

(952) 448-5300 • Fax (952) 448-2613 • (800) 448-0121

Email: [sales@acousticalsurfaces.com](mailto:sales@acousticalsurfaces.com)

Visit our Website: [www.acousticalsurfaces.com](http://www.acousticalsurfaces.com)

---

---

**We Identify and S.T.O.P. Your Noise Problem**

## EQUIPMENT USED FOR TESTING

Thermo Mattson Satellite FTIR  
Thermo Spectra Tech Foundation Series HATR  
Hiac-Royco 8103 LPC

## SPECTRUM APPENDIX

### Spectrum 1

ARPRO EPP material

Peaks: 2953.00, 2922.99, 2852.99, 1539.50, 1463.90, ethyl group; 1742.18,  
1163.25 R2-C=CH<sub>2</sub>; 1539.50, 1377.31 methyl group; 1742.18 ester.

The results provided in this report are accurate within the limits appropriate to each test standard. The results of this report are statistically significant only to the samples submitted for testing. MicroStat Laboratories has no controls, and assumes no responsibility for the tested product's functionality or use.

Michael Tosolini

10/25/06

Date

Carl E Newberg

10/25/06

Date

Report #: 2006-129

MicroStat Laboratories / River's Edge Technical Service  
Page 3 of 3

October 25, 2006